



FujiFilm FinePix S4500 LCD Replacement

Follow these steps to remove the LCD screen on the camera.

Written By: Vicente Rios



INTRODUCTION

The LCD is one of the most critical parts on the camera. This guide will show you how to remove the back panel of the camera in order to replace a faulty LCD screen.



TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #1 Screwdriver](#) (1)



PARTS:

- [FujiFilm FinePix S4500 LCD screen](#) (1)
- FujiFilm

Step 1 — LCD



- Remove the two 3.5 mm Phillips #1 screws in these positions on the left side of the camera with a screwdriver.

Step 2



- Remove the three 3.5 mm Phillips #1 screws in these locations on the bottom of the camera with a screwdriver.

Step 3



- Remove the four 3.5 mm Phillips #1 screws in these positions on the right side of the camera with a screwdriver.

Step 4



- Use a plastic opening tool to separate the back panel from the camera on the left side.

Step 5




- Use a plastic opening tool to separate the back panel from the camera on the bottom.

Step 6




- Use a plastic opening tool to separate the back panel from the camera on the left side, then remove the back panel from the camera.

Step 7



- Use a plastic opening tool to separate the LCD screen from the camera.

Step 8



- Flip up the black tab holding the LCD ribbon wire in place and remove wire.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-10 06:26:41 AM.

